

PARTS LIST FOR LIFTOMATIC DOUBLE CLAMPING MECHANISM
MODEL DCM-BC

<u>ITEM</u>	<u>PART</u>	<u>QTY</u> <u>REQ'D</u>	<u>DESCRIPTION</u>
1	2026	1	OUTER HOUSING (DOUBLE)
2	2097	2	INNER HOUSING
3	7001	2	UPPER JAW, CLAMP
4	7015	2	LOWER JAW, CLAMP
5	14027	2	PIN, LINK TO UPPER JAW
6	16001	2	PIN, UPPER JAW TO HOUSING
7	19007	4	LINK, JAW TO JAW
8	6034	2	SPRING, JAW TO JAW
9	14026	2	PIN, LINK TO LOWER JAW
10	6999	2	HOOK, HOUSING SPRING
11	6022	2	SPRING, HOUSING TO HOUSING
12	16008-1	2	PIN, HOUSING TO HOUSING
13	6006-CP	4	COTTER PIN
14	6101	2	CAP SCREW, 3/8"-16 X 1 1/4" LG.- M10x1.5-32mm
15	6077	2	LOCK WASHER, 3/8"
16	43020-1	1	SPACER, UNIVERSAL BODY
17	2029	1	UNIVERSAL BODY
18	6102	1	BOLT/TRUNNION 1/2"-13 X 1 1/4" LG.- M12x1.75-45mm
19	6091	1	LOCK NUT, TRUN BOLT, 1/2"-13 (OR NUT & WSHR)
20	10001	1	BUSHING, HOUSING YOKE TRUNNION
21	19006-1	1	WEAR PLATE, UNIVERSAL CARRIER
22	2027	1	UNIVERSAL CARRIER
23	16019-1	1	ADJUSTMENT PIN
24	16015-1	1	PIN, UNIVERSAL BODY TO CARRIER
25	6006-CP	1	COTTER PIN
26	7007-1	2	ADJUSTMENT SLIDE
27	6998	1	HOOK, CLEVIS SPRING
28	6107	1	HAIR PIN CLIP, ADJUSTMENT PIN
29	2023	2	CLEVIS
30	16007-1	2	PIN, CLEVIS TO UNIVERSAL CARRIER
31	6006-CP	4	COTTER PIN
32	6024	2	SPRING, CLEVIS
33	16057	1	NEW STYLE 'RING' CARRIAGE LOCK PIN **
34	6046	1	SPRING/WASHER/ROLL PIN TO #33 **
			** For #33 or #34, Order Assembly #4081
35	2094	1	BELT CRADLE FRAME (BELT INCLUDED)
36	6152	1	ALL PURPOSE COTTON-NYLON BELT
	6153	1	RUBBER BELT
	6158	1	PVC BELT
	6159-SRJ	1	SPARK RESISTANT BELT
37	40022-1	2	BELT CLAMP
38	6092	4	HEX NUT, 5/16"-18 (#6106 BOLT INCLUDED)
39	2096	1	CLAMP/ADJUSTING ROD
40	6093	2	HEX NUT, 5/8"-11
Not Shown	4050*	1	SAFETY CHAIN & CLAMP (HEAVY DUTY)

ASSEMBLIES

ITEMS # 2 THRU # 9 INNER HOUSING & CLAMP MECHANISM..... P/N 4033
 ITEMS # 1 THRU # 32 COMPLETE CLAMP ASSY. LESS FRAME..... P/N 4006

*Includes P/N 4050 Safety Chain (#2149 Clamp / #16004 Pin / #6009-CP Cotter Pin --2 Req'd.)

