



**Liftomatic Material Handling, Inc.**

700 Dartmouth Lane  
Buffalo Grove, IL 60089

Phone 847 325-2930  
Fax 847 325-2959  
Toll Free 800 837-6540

**Ergo-Matic® Drum Transporter Part List**

No.	Part #	Qty	Description
1.	6174	2	Swivel Caster
2.	6092	14	Hex Nut
3.	6079	14	Lock Washer
4.	6303	14	Flat Head Screw
5.	6270	1	Hydraulic Jack
6.	6094	4	Hex Nut
7.	6302	2	Hex Head Bolt
8.	6078	4	Lock Washer
9.	19053	1	Jack Clamp
10.	2204	1	Anchor Pin
11.	6062	2	Tapered Pin
12.	6271	1	Lift Chain
13.	2197	1	Jack, Clevis
14.	6306	1	Set Screw
15.	6305	4	Round Head Screw
16.	2203	1	Chain Guard
17.	6197	1	Grease Fitting
18.	16055	1	Chain Sheave
19.	6180	1	Sleeve Bearing
20.	16054	1	Axle
21.	6995	2	Hand Grip
22.	2192	1	Main Frame
23.	14023	1	Adjusting Pin
24.	2193	1	Inner Frame
25.	6003	4	Cotter Pin
26.	6015	8	Shim
27.	8004	4	Roller
28.	6123	2	Socket Head Screw
29.	2198	1	Chain Anchor
30.	6097	2	Hex nut
31.	4009	1	Clamping Mechanism
32.	6063	1	Circular Cotter
33.	6307	2	Wheel Axle
34.	6175	2	Front Wheel Assembly
35.	6077	2	Lock Nut
36.	6301	2	Hex Head Bolt
37.	6304	4	Flat Head Screw
38.	37211	1	Top Cover
39.	6176	1	Floor Lock
40.	2194-L	1	Left Leg W/M
41.	2194-R	1	Right Leg W/M

